

Cow Hitch

Disconnection assisted by the use of a Pig tail.

User Manual

1. Connect the main rope and mooring tail by creating a cow hitch as shown on the pictures below:




2. Enter the pig tails in between the eyes as shown in picture below:



3. Tension the cow hitch and attach the loose ends to either side.



4. Disconnect the cow hitch by pulling Pig tail ropes to each side to open.



Wilhelmsen Ships Service
Phone: (+47) 6758 40 00
Fax: (+47) 67 58 40 80

Postal Address:
PO Box 33, NO-1324
Lysaker, Norway

wilhelmsen.com